# Digital Multimeter(DMM) Tutorial (Agilent U3401A)

**ECE 401** 

Perspectives in Electrical and Computer Engineering

#### Outlines:

- ✓ What is multimeter? What does multimeter measures?
- ✓ Multi-function description
- ✓ Multimeter connections

## What is multimeter? What does multimeter measures?

It is an electronic instrument used to measure electric voltage, current and resistivity.


➤ Multimeters provide the flexibility to measure different electrical properties rather than using individual meters.

## Multi-function description




Press to power-on or power-off the U3401A multimeter.

## Multi-function description cont.




#### Multi-function description cont.



DCV	Press to select the DC voltage measurement.
ACV	Press to select the AC voltage measurement.
DCI	Press to select the DC current measurement.
ACI	Press to select the AC current measurement.

## Multi-function description cont.





Press to toggle between resistance or resistance continuity.




Press to toggle between manual ranging and autoranging

#### Multimeter connections


To explain the measurement features of DMM, two resistor-based circuits are presented.

☐ The First circuit is consists of a D.C power supply and two resistors connected in series as follows:





## To measure the voltage a cross a particular resistor (see the illustration figure next slide):

- Connect the red prop between the DMM red voltage terminal and the positive side of the resistor in the circuit.
- ➤ Connect the black prop between the DMM black voltage terminal and the negative side of the resistor in the circuit.
- Press the pushbutton (DCV) on the DMM to read the voltage measurement across the resistor.



The second circuit is consists of a D.C power supply and two resistors connected in parallel (as it is illustrated in next slide):





The current (I<sub>R</sub>) can be measured using the obtained voltages in previous circuits (series, parallel) by applying Ohm's law:

$$I_R(Amp) = \frac{V_{R(Volt)}}{R(\Omega)}$$

Where  $V_R$  is the voltage across resistor (R)